

Fire Extinguisher Mount - Universal

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

Check to make sure you have all parts listed prior to installation. If anything is missing contact us immediately.





1. Remove seat or disconnect and tip seat back in the car. Depending on your application, one method may be easier then the other.

2. Based on you application, determine the mounting location for the 90 degree brackets.

3. Take a measurement between the 90 degree brackets. If the bracket extensions will be used, take this into consideration.

4. Assemble the unit as shown above. Depending on your application, there are many options to set the mount height and depth. Adjust as needed.

5. Install the assembly between the 90 degree brackets.

6. Re-install the seat into car and make final adjustments.

7. Torque the clamp set screw to 13 ft lbs and the mount tube bolts to 45 ft lbs

· P/N - FE09 - 05/12