

Gear knob installation instruction.

Step 1: Remove shift knob and boot from car. Some knobs have set screws others simple pull off. Check your specific model for the proper method.



Step 2: For cars with integrated boot/knob, use a razor blade to cut the factory boot all the way around base of the factory knob leaving boot as long as possible. Remove factory knob from the boot. For cars without integrated boot/knob, skip to step 3.



Step 3: Turn the boot inside out and insert the knob until the base of the knob is even with the base of the boot. Install rubber O-ring over the boot and align with the groove in the knob.



Step 4: Pull the knob out of the boot until the O-ring will not allow you to pull any further. Re-install shift boot/knob assembly. Set desired height of the shift knob and tighten the set screws at the base of the knob.

